


Instruction Manual

Calibre : 8172 / 220

Function : Analog Chronograph with 30 min. Counter, Day and Date

Illustration



SETTING	<p>★ Setting the time (Hour & Minute)</p> <p>0.1 0.2</p>	<p>★ Setting the day</p> <p>24H00 RESET</p> <p>1.1 1.2</p>	
	<p>★ Setting the date (Caution: Never correct date between 9 PM to 0:30AM)</p> <p>2.1 2.2</p>		
CHRONO FUNCTIONS	<p>★ Measuring cumulative time</p> <p>After 2 hours of continuant running, the chrono stops and resets automatically to save the battery</p> <p>START STOP RESET</p> <p>A A B</p> <p>3.1 3.2 3.3</p>		
	<p>★ Measuring split time</p> <p>START STOP (SPLIT) RESTART STOP RESET</p> <p>A B B A B</p> <p>4.1 4.2 4.3 4.4 4.5</p>		
CALIBRATION	<p>★ To reset chronograph minute and second chronograph (After battery exchange or mishandling only)</p> <p>ENTER MINUTE SECOND RESET</p> <p>5.1 5.2 5.3 5.4</p>		
INFO	<p>Battery : Typ. 399 – SR927W or 395 – SR927SW</p>		